



High resolution CT-based characterization analysis of idiopathic pulmonary fibrosis

Yuwen Zhang, Merryn Tawhai, Alys Clark, Haribalan Kumar
David Milne, Margaret Wilsher, Brian Bartholmai

- Idiopathic pulmonary fibrosis (IPF) is a chronic and life-threatening disease
- Cause is unknown
- Etiology remains elusive
- Progression is variable and unpredictable



- HRCT is an essential tool in evaluating lung disease
- Associated with the presence of a usual interstitial pneumonia (UIP) pattern on HRCT (ATS/ERS criteria)
- Honeycomb, reticular, ground-glass



Currently published work:

- Quantitative analysis of radiological images
- Clinical functional measurements




Radiological images may be not sufficient enough to explain the decline of lung function

Limited research into combining spatial data with functional data.

No established quantitative tools to assess the progression of IPF

Aim



Imaging and clinical data

Clinical data assessed in this study	
Age (years)	43-82
Females/Males	3/5
Slice thickness (mm)	1.25-3.00
Interval between scans (months)	5-20
Slice resolution	512x512
Number of slices	65-160


The clinical data used in this study comprised HRCT images and pulmonary function tests obtained from 8 patients diagnosed with IPF at Auckland City Hospital, Auckland, New Zealand.

5 patient → 1 time point
1 patient → 2 time point
2 patient → 3 time point

Pulmonary parenchymal classification

CALIPER (Computer-Aided Lung Informatics for Pathology Evaluation and Ratings) software.
Mayo Clinic (Rochester, MN, USA)

Each parenchymal voxel was classified into the following characteristic CT patterns: normal (N), reticular (R), honeycomb (HC), ground-glass (GG), mild low attenuation areas (LAA), moderate LAA and severe LAA. Emphysema : Hounsfield Unit is under -950.




Color labelled classification result of case 7 on IPF HRCT by CALIPER. (a) Transverse plane. (b) Coronal plane. (c) Sagittal plane. (d) 3D color labelled lung.


By. Brian Bartholmai

- Lung mesh : bi-cubic Hermite finite element surface mesh (left lung: 35 nodes and 44 elements; right lung: 50 nodes and 62 elements)
- Classified data mapping : statistical shape model (SSM), principal component analysis (PCA)


Time point 1



Time point 2





Time point 3



Density analysis


- Fibrosis usually has a consistently higher tissue density (0.34/0.41 for reticular/ground-glass) compared to normal tissue (0.27) over time
- In contrast, emphysema has lower density (0.078)



Spatial distribution analysis


Ground-glass

Left lung Groundglass disease distribution against lung height




Emphysema


Left lung Emphysema disease distribution against lung height



Groundglass lobar distribution



Emphysema lobar distribution



- Fibrosis mostly located in lower lobes (72%, 58%, 65% for honeycomb, reticular, ground-glass)

- Emphysema mostly located in upper lobes (73%)

SSM based shape analysis


Training data
collection
(35 older normal)

Principle component
shape feature analysis



Statistical shape model
construction

Specific subject
projection


Inspiration Mode1 Distribution




Mode 1 weight VS Fibrosis




IPF patient-specific airway tree geometry




Manually digitize upper airway



Generate full airway tree
of time point 1



Map first airway tree to
other time points




Scale the airway tree (length and
radius) to FRC volume



Disease spatial
distribution

Disease percentage
against
gravitational height




Label each terminal acinar unit
with different CT patterns

IPF patient-specific ventilation analysis


Forced inspiration

Reference FRC – TLC: set muscle pressure


Real FRC – TLC: set real abnormality distribution



Fibrosis: 17.64%(from CT)



Fibrosis: 29.75%




- abnormalities on volumetric data are not sufficient to explain increased lung stiffness



IPF patient-specific gas exchange analysis

Perfusion analysis:

- parameterize the model inputs
- generate vessel geometry
- reduce the vessel radius of disease labelled region



V/Q ratio distribution



- Combine quantitative characterization extracted from volumetric CT with PFTs to parameterize the computational model
- Simulate basic lung function
- Shape difference between IPF lungs and old normal lungs (PCA based SSM)
- The decline of lung function could not be fully explained by radiological tissue abnormalities

Thank you